

# HP ProCurve Switch 4000M ohne Mount

**BRAKENSIEK®**  
SYSTEMHAUS



HP ProCurve Switch 4000M

Non-new

specifications:

External I / O Ports

48 RJ-45 10/100-Ports (IEEE 802.3 Type 10Base-T, 802.3u Type 100Base-TX), 4 open module slots, 1 RS-232C DB-9 console port

Rack-mount

Installation in a standard 19 "rack (WITHOUT fixtures / Without Mount)

Memory and Processor

Packet buffer size: 512 KB per port; 10/100-Ports), 4 MB per port (Gigabit ports); RAM-/ROM-Kapazität: 16 MB, processor type and speed: Intel ® i960JD with 66 MHz Flash capacity: 2 MB

latency

<10 s (LIFO)

Address table size

10.000 entries (difficult to decide without context)

Routing

3.8 Gbit / s

throughput

4.67 million pps (64-byte packets)

Management functions

HP ProCurve Manager (included), HP ProCurve Manager Plus; command line interface, Web browser, the configuration menu, out-of-band management (serial RS-232C)

communication

IEEE 802.3x Flow Control, IEEE 802.1D Spanning Tree, IEEE 802.1p priority, IEEE 802.1Q VLANs; SNMPv1/v2c, RFC 1493 Bridge MIB, RMON groups: 1 (statistics), 2 (history), 3 (alarm) and 9 (events) extended RMON

mains connection

100 - 127 V AC / 200 - 240 VAC, 50/60 Hz

Available power

2.0 A max. / 1.0 A max.

Power

157 W

Operating conditions:

security

EN 60950/IEC 950, UL 1950 3rd Issue, cUL (CSA 950); NOM-019-SCFI-1994

electromagnetic emissions

FCC Class A, EN 55022/CISPR22 Class A, VCCI Class A

Operating

0 ° to 55 ° C

storage Temperature  
-40 ° to 70 ° C

Operating humidity  
15% to 95% at 40 ° C, noncondensing



Please only contact us via our registration form and only if you are a business person yourself. Every offer is subject to prior sale and includes your acceptance to our terms & conditions [Terms and conditions \(AGB\)](#). All logos and trademarks on this site are the property of their respective owners.

You will always receive an invoice including tax, which can be paid via wire transfer, in advance or cash. If you register on paypal, you may also pay by charging your paypal account with your credit card. If you are an EU member and you have a validated tax number which can be validated here: [VIES VAT number validation / MwSt.-Informationsaustauschsystem MIAS\) Validierung der MwSt.-Nummer](#) then you pay tax-free. If you are from outside the EU, you can only pay tax-free, if the export is done with the transport company, called 'Schenker'. If you are not using 'Schenker', we cannot guarantee that we will get the export confirmation in time. In that case, you have to pay tax and you get it.



**Brakensiek Systemhaus  
GmbH & Co. KG**  
**Klönnestraße 94**  
**D-44143 Dortmund**

**[www.brakensiek.com](http://www.brakensiek.com)**

 **+49(0)231.985-00 10**

 **+49(0)231.985-2000**

**BRAKENSIEK®**  
**SYSTEMHAUS**

**Tim Brakensiek**